

SHAD

BMW F 850GS / 750GS '18 KIT TOP W0FS88ST



1 262333 x1 →
262334 x1 ←



2 260954 x6
Ø14 Ø9 x 16



3 304029 x2
M6 x 35 DIN 7991



4 304201 x4
M6 x 40 DIN 7380



5 303017 x4
Ø6

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

